

Setting up VAC with SDRuno

6/19/2017

Virtual Audio Cable software allows you to transfer audio (wave) streams between applications and/or devices.

It creates a set of <u>virtual audio devices</u> named "**Virtual Cables**", each of them consists of a pair of the waveform input/output devices. Any application can send audio stream to an output side of a cable, and any other application can receive this stream from an input side. All transfers are made <u>digitally</u>, providing **NO** sound quality loss (a bit perfect streaming).



VAC is not a free utility. Download and install VAC from the link below. http://software.muzychenko.net/eng/vac.htm

SDRplay

Launch the VAC control panel

E *	tal Auto Cate Conto Reef	Sec. 1
	a za santali se ter 1 → 2 min ter	
Case	Xeet context Infiliation 2x6 Exec context ME Strange Mininger Min	
06.06 	1935532275 Golde Lynerder sitean 2. terminand 19g Cearling System theorysts, mor. 2000 - Rentert Audo Stypine About. Heb Exit	
		Rplay
Z Virtual Audio Cable Control Panel		
Cables 1 ÷ Set Clients 7	Cable parameters Format range	Connected source lines
Streams 1	SR 22050 • 48000 • BPS 8 • 16 • NC 1 • 2 •	I MIC IV LINE I S/PDIF
Timer res, mcs 3500		
Up to Auto Log level 7	Max inst 20 Ms per int 7 Stream fmt limit Cable range Clock corr ratio Stream buffer watermark control	100.0000000 🔆 🔽 Volume control
Up to Auto Prio Auto Set	Max inst 20 • Ms per int 7 • Stream fmt limit Cable range • Clock corr ratio Stream buffer watermark control Finabled Low 50 • ms High 200 • ms Max wait 300 • ms	100.0000000 ÷ Volume control able channel mixing Enable spk pin e PortCls Stream buffer (ms) Auto v
Up to Auto Prio Auto Reset counters Restart	Max inst 20 • Ms per int 7 • Stream fmt limit Cable range • Clock corr ratio Stream buffer watermark control Enabled Low 50 • ms High 200 • ms Max wait 300 • ms Use Info	100.0000000 ÷ Volume control able channel mixing Enable spk pin PortCls Stream buffer (ms) Auto v Set Reset counters
Vorker direads Timer res, mcs 3500 Up to Auto • Log level 7 • Prio Auto • Set Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 22050, 48000 8, 16 1, 2	Max inst 20 Ms per int 7 Stream fmt limit Cable range Clock corr ratio Stream buffer watermark control F Enabled Low 50 ms High 200 ms Max wait 300 ms Use Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off On Off Off ExtPCM/48000/16/2(3) 1	100.000000 Volume control able channel mixing PortCls Stream buffer (ms) Auto Set Reset counters Pb stms Signal Oflows UFlows O
Vorket direads Timer res, mcs 3500 Up to Auto • Log level 7 • Prio Auto • Set Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 2205048000 816 12	Max inst 20 Ms per int 7 Stream fmt limit Cable range Clock corr ratio Stream buffer watermark control Image: Clock corr ratio Image: Clock corr ratio Image: Clock corr ratio Image: Clock corr ratio Enabled Low 50 ms High 200 ms Max wait 300 Image: Clock corr ratio Image: Clock cor	100.000000 Volume control able channel mixing PortCls Stream buffer (ms) Auto Set Reset counters Pb stms Signal Oflows UFlows O
Vorker dreads Timer res, mcs 3500 Up to Auto Log level 7 Prio Auto Set Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 22050.,48000 816 12	Max inst 20 ✓ Ms per int 7 ✓ Stream fmt limit Cable range ✓ Clock corr ratio Stream buffer watermark control ✓ Fna ✓ Enabled Low 50 ✓ ms High 200 ✓ ms Max wait 300 ✓ ms ✓ Enabled Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off Off Off ExtPrcM/48000/16/2(3) 1	100.000000 Volume control able channel mixing PortCls Stream buffer (ms) Auto Set Reset counters Pb stms Signal Oflows UFlows O
Vorker dreads Timer res, mcs 3500 Up to Auto Log level 7 Prio Auto Est Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 2205048000 816 12	Max inst 20 V Ms per int 7 Stream fmt limit Cable range Clock corr ratio Stream buffer watermark control Enabled Low 50 V ms High 200 V ms Max wait 300 V ms Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off On Off Off ExtPrcM/48000/16/2(3) 1	100.000000 ÷ Volume control able channel mixing Enable spk pin e PortCls Stream buffer (ms) Auto v Set Reset counters Pb stms Signal Offows UFlows 0
Vorker threads Timer res, mcs 3500 Up to Auto Log level 7 Prio Auto Set Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 2205048000 816 12	Max inst 20 ▼ Ms per int 7 ▼ Stream fmt limit Cable range ▼ Clock corr ratio Stream buffer watermark control ▼ Enabled Low 50 ▼ ms High 200 ▼ ms Max wait 300 ▼ ms Use Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off On Off Off ExtPCM/48000/16/2(3) 1	100.000000 🔆 Volume control able channel mixing Enable spk pin e PortCls Stream buffer (ms) Auto v Set Reset counters Pb stms Signal Oflows UFlows 0
Vorker direads Timer res, mcs 3500 Up to Auto Log level 7 Prio Auto Reset counters Restart Cable MS SR range BPS range NC range 1 7 22050,,48000 8.,16 1.,2	Max inst 20 ▼ Ms per int 7 ▼ Stream fmt limit Cable range ▼ Clock corr ratio Stream buffer watermark control ▼ Enabled Low 50 ▼ ms High 200 ▼ ms Max wait 300 ▼ ms □ Use Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off Off Off ExtPCM/48000/16/2(3) 1	100.000000 Volume control able channel mixing PortCls Stream buffer (ms) Auto Set Reset counters Pb stms Signal Oflows UFlows O
Vorker dreads Timer res, mcs 3500 Up to Auto Log level 7 Prio Auto Set Set Reset counters Restart Cable MS SR range BPS range NC range 1 7 22050.,48000 8.,16 1.,2 06.06 08:55:52.275 Cable 1, render stream 2: terminate	Max inst 20 V Ms per int 7 Stream fmt limit Cable range Clock corr ratio Stream buffer watermark control Enabled Low 50 V ms High 200 M ms Max wait 300 M ms Use Info Stm fmt limit St buf Vol ctl Ch mix PortCls WM ctl Current format Rc stms Cable range Auto Off On Off Off ExtPCM/48000/16/2(3) 1	100.000000 ÷ Volume control able channel mixing Enable spk pin e PortCls Stream buffer (ms) Auto • Set Reset counters Pb stms Signal Offows UFlows 0

* Start by setting 1 cable in the cables section and click Set. * Click the Exit button after the cable is set.

SDRplay

Set the Virtual Audio Cables to send and receive audio inside the operating system.

				_ _ X	C Storet X
Control Panel + All Con	deal Panel Borna 🔹			44 Search Central Panel P	Herbeck Recording Sounds Communications
Adjust your computer's settings				View by: Large cores +	Select a polydaek derine below to modify its settings:
Action Center	Administrative Tools	AutoPlay	Backup and Restore	Color Management	Spaker USB Audie CODEC USB Audie CODEC
Credential Manager	Date and Time	Default Programs	Desktop Gadgets	Device Manager	Line 1 Virtual Austra Cable Really.
Devices and Printers	Display	Ge Ease of Access Center	Folder Options	Fonts	
Getting Started	NomeGroup	Indexing Options	Intel(R) Graphics and Media	Tools	
Internet Options	Se Keyboard	Denovo - Power Controls	Location and Other Sensors	Mail (Microsoft Outlook 2016) (32-bit)	Configure Set Default V Appetter
I Mouse	Network and Sharing Center	Notification Area Icons	Parental Controls	Performance Information and Tools	
Personalization	Phone and Modem	Power Options	Programs and Features	Recovery	😥 Lite 1 Properties
🔗 Region and Language	RemoteApp and Desktop Connections	Sound	Greech Recognition	Sync Center	Genera Levels Advanced
System	Taskbar and Start Menu	Troubleshooting	User Accounts	Windows Anytime Upgrade	Line 1 100 (1) Balance
Windows CardSpace	Windows Defender	Windows Firewall	Windows Mobility Center	Windows Update	Manyahan
					100
					OK Centel Activ
					. 4
					SURplau

- * Navigate to the Control Panel and double click Sound.
- * Select Playback.
- * Select Level.
- * Set your Level as shown.
- * Click OK.

Set the Virtual Audio Cables to send and receive audio in the operating system.

Image: Partie Control Root Provided Programs Image: Partie Control Root Provided Programs Image: Partie Control Provided Programs Image: Partie Control	Image: Pole construint	Image: Construite in the set of Construitement in the set of Construit in the set of Constr						Sound	
Adjust your computer's stritigs total your computer's strit your computer's stritigs <tht and="" does="" th="" your<=""><th>Action Center Color Management</th><th>Action Center Credential Manager Deta and Time Deta beside Time</th><th>💮 💮 - 📴 🔹 Control Panel 🔹 All Cort</th><th>crol Panel Items 🔹</th><th></th><th></th><th>Search Control Panel</th><th>Playback Recording Sound</th><th>Communications</th></tht>	Action Center Color Management	Action Center Credential Manager Deta and Time Deta beside Time	💮 💮 - 📴 🔹 Control Panel 🔹 All Cort	crol Panel Items 🔹			Search Control Panel	Playback Recording Sound	Communications
** Action Center ** Administrative Tools: ** Adaptive ** Exclup and Restore ** Color Management *** Action Center *** Descend Theorem *** Des	** Action Center ** Action Activity Activity Earlier Code ** Action Activity	 Action Center Activitizative Tools. Activitizative Tools. Activitizative Tools. Activitizative Tools. Dete and Time Debuild Programs Programs P	Adjust your computer's settings				New by Large icons *	Select a recording device b	elow to modify its s
Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Condential Manager Image: Co	Image: Standed Manager Image: Devices and Printers	Image: Credential Manager Image: Delate and Time Image: Delate and Time <t< td=""><td>Action Center</td><td>Administrative Tools</td><td>AutoPlay</td><td>Backup and Restore</td><td>Color Management</td><td>Mesophene USB Audio (2 Diffust Device</td><td>DEC</td></t<>	Action Center	Administrative Tools	AutoPlay	Backup and Restore	Color Management	Mesophene USB Audio (2 Diffust Device	DEC
Image: Started Image	Image: Standed Image	Image: Started Image	Credential Manager	Date and Time	Default Programs	Desktop Gadgets	Device Manager	Vistual Au Ready	Disable
image: Control in the standing Standed image: Control in the standing Standed image: Control in the standed <	Image: Started Image: Proceeding Started Image: Proceeding	Genting Standal Genting Standal Quint location Quint location Unint location Unint locati	Devices and Printers	Display	Ease of Access Center	Folder Options	A Fonts		Set as Default Der Set as Default Co
Internet Options Image: Network and Sharing Image: Ne	Internet Options Image: Network and Sharing Image: Ne	Instruct Options Image: Series of Series	Getting Started	RomeGroup	Indexing Options	Intel(R) Graphics and Media	Tools		Show Disabled De Show Disconnect
• Mouse • Mous	Image: System Image: System<	Mouse Instruct and Starling Instruct and Starling Instruct and Starling Instruct and Starling Personalization Image Phone and Modern Image Phone Ceptions Image Personalization Image Phone and Modern Image Phone and Fastures Image Recovery Image Region and Language Image Connections Image Phone and Fastures Image Recovery Image System Image Touble-shooting Image Touble-shooting Image User Accounts Image Vindows Anytime Image Vindows CardSpace Image Vindows Frewall Image Vindows Mobiliny Center Image Vindows Update	1 Internet Options	Keyboard	Denovo - Power Controls	Location and Other Sensors	Mail (Microsoft Outlook 2016) (32-bit)	Cotto	Properties
Image: Space and Modern Image: Proper And Modern Image: Proper And Modern Image: Proper And Proper And Property Proper	Image: System Imag	Image: Processization Image: Processiza	J Mouse	Network and Sharing Center	Notification Area Icons	Parental Controls	Performance Information and Tools	(compare	OK C
Image: System Imag	Region and Language Region and Language Region and Language Speech Recognition Sync Center System Image: Taskbar and Start Menu Image: Traubleshooting Start Menu Windows Anytime Windows CartSpace Sign Vindows Defender Swindows Firewall Start Windows Mobility Center Windows Update	Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Windows CardSpace Image: Windows Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Windows CardSpace Image: Windows Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Windows CardSpace Image: Windows Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Windows CardSpace Image: Windows Recognition Image: Speech Recognition Image: Speech Recognition Image: Speech Recognition Image: Windows CardSpace Image: Windows Recognition <td< td=""><td>Personalization</td><td>Phone and Modem</td><td>Power Options</td><td>Programs and Features</td><td>Recovery</td><td></td><td></td></td<>	Personalization	Phone and Modem	Power Options	Programs and Features	Recovery		
La System I takkar and Start Menu I is Troubleshooting & Uer Accounts A Modow Engline Upgrade I Windows Christipace Mindows Detender. I Windows Friendli I Windows Hobbilly Center I Windows Updrate	🖳 System II Taskbar and Start Menu III Troubleshooting 🤮 User Accounts 🕰 Windows Anytime Upgrade III Windows CardSpace IIII Windows Defender 🔐 Windows Firewall IIII Windows Mobility Center 🖓 Windows Update	🞼 System 📃 taskbar and Start Menu 🕞 Troubleshooting 😣 User Accounts 🥰 Windows Angline Upgrade 1 Windows CardSpace 🍇 Windows Detender 💣 Windows Firevall 😱 Windows Mobility Center 🖓 Windows Update	Begion and Language	RemoteApp and Desktop Connections	Sound	Speech Recognition	Sync Center		
🦉 Windows CardSpace 👹 Windows Defender 👹 Windows Firewall 🐺 Windows Mobility Center 🖉 Windows Update	🚶 Windows CardSpace 👹 Windows Detender 👹 Windows Firewall 👔 Windows Mobility Center 🖓 Windows Update	😻 Windows CardSpace 👪 Windows Detender 💣 Windows Fizewall 😱 Windows Mobility Center े Windows Update	System	Taskbar and Start Menu	Troubleshooting	Ser Accounts	Windows Anytime Upgrade		
			Windows CardSpace	Windows Defender	Windows Firewall	Windows Mobility Center	Windows Update		
								SARA	
	SORala								1-1

- * Navigate to the Control Panel and double click Sound. * Select Recording.
- * Right click on Line 1.
- * Left click on Set Default Device.
- * Click OK.

SDRplau

Launch SDRuno



- * Inside the RX CONTROL module hit SETT.
- * Click the right arrow icon in the RX Settings 0 0 panel and select the OUT section.
- * Under the WME Output Device select your Line 1 (Virtual Audio Cable).
- * Click the top right x inside the RX Settings panel.
- * Click PLAY! In the MAIN Module.

SDRplay

Launch your decoder of choice. I used CW Decoder Logic a Morse decoder in this example.



* Inside any decoder you will select your Line 1 (Virtual Audio Cable). for the Recording Device.

SDRplay

Fine tuning SDRuno.



* Before you hit PLAY in the MAIN module remember to give yourself separation between the Tuned frequency and LO frequency inside the MAIN SP window (click to the right inside the MAIN SP window) b: To help minimize garbled text for digital modes that are not continuous you can enable the squelch feature in SDRuno (RX Control module) to act as a simple audio gate.

SETT.	RDSW	EXW	SDRu	no RX CO	NTROL	f	RSYN1	MCTR	TCTR	9-88	- X
	STEP: 250 Hz		14	101	7.18	53*	02.5 dBm	RMS	. <u></u>	7 9 4	0 +40 +60
MODE	AM	SAM	FM	CW	DSB	LSB	USB	DIGITAL			
VFO	- QM	FM N	ODE	CW OP	FIL	TER	NB	NOTCH	7-	8	9
VFO A	A > B	NFM	МЕМ	CWPK	150	250	NBW	NCH1	160	80	40
VFO B	B > A	WFM	SWFM	ZAP	500	750	NBN	NCH2	4	0	6
QMS	QMR			CWAFC		NR	NBOFF	NCH3	- 30	20	1/
-73 dB						AGC		NCH4	15	2 12	3 10
SQLC						OFF	FAST	NCHL			
MUTE						MED	SLOW		2	Clear	Enter