




Decoding MIL-ALE using SDRUno and MultiPSK

6/18/2017

Automatic Link Establishment is the worldwide de facto standard for digitally initiating and sustaining HF radio communications. [1] ALE is a feature in an HF communications radio transceiver system that enables the radio station to make contact, or initiate a circuit, between itself and another HF radio station or network of stations. The purpose is to provide a reliable rapid method of calling and connecting during constantly changing HF ionospheric propagation, reception interference, and shared spectrum use of busy or congested HF channels.



You will need either VB-Cable or VAC installed and configured. This will allow you to pipe the audio out of SDRUno into the MultiPSK decoder.

<http://vb-audio.pagesperso-orange.fr/Cable/>

<http://software.muzychenko.net/eng/vac.htm>


Finding ALE Networks you can monitor & decode.

* Visit Radio Reference for ALE network information and frequencies.
http://wiki.radioreference.com/index.php/ALE_Networks


* Launch SDRUno and select the network you want to monitor (note the frequency). The Mode is SDRUno is USB with a filter set at 3.0k.



* Launch MultiPSK and select 141A (ALE)



* Wait for the distinct ALE burst and watch the lower decoder section of MultiPSK.



HF-ALE Networks to get started.

UOS Air Force GHFS ALE Network

ALE Address and Frequency Chart

Station	ALE	Frequency										
		Address	3137	4721	5708	6721	9025	11226	13215	15043	18003	23337
Andrews	ADW		x	x	x	x	x	x	x	x	x	x
Ascension	HAW		x	x		x	x	x	x	x	x	x
Croughton	CRO		x	x		x	x	x	x	x	x	x
Diego Garcia	JDG		x	x	x	x	x	x	x	x	x	x
Elmendorf	AED		x	x	x	x	x	x	x	x	x	x
Guam	GUA		x	x	x	x	x	x	x	x	x	x
Hawaii	HIK		x	x		x	x	x	x	x	x	x
Keflavik	IKF		x	x	x	x	x	x	x	x	x	x
Lajes	PLA		x	x	x	x	x	x	x	x	x	x
McClellan	MCC		x	x	x	x	x	x	x	x	x	x
Offutt	OFF		x	x	x	x	x	x	x	x	x	x
Salinas	JNR		x	x	x	x	x	x	x	x	x	x
Sigonella	ICZ		x	x	x	x	x	x	x	x	x	x
S Atlantic	MPA		x	x	x	x	x	x	x	x	x	x
West Coast	MCC		x	x	x	x	x	x	x	x	x	x
Yokota	JTY		x	x		x	x	x	x	x	x	x

US Air Force SIPRNET ALE Network

5702.0
5708.0
6715.0
8968.0
11181.0
17976.0
27870.0

US Air Force NIPRNET ALE Network

3068.0
4745.0
5684.0
8965.0
11199.0
13242.0
17973.0
20631.0

US Army Flight Watch Service (Southern Command)

All Frequencies USB

8065
8972
12022
16144.5
19103.5

US Army National Guard

4882.0
4924.5
5202.0
8047.0
10816.5
14653.0
16338.5
17458.5

CBP / DHS COTHEN Network

5732.0
7527.0
8912.0
10242.0
11494.0
13907.0
15867.0
18594.0
20890.0
23214.0
25350.0